

Kentatsu air conditioners KSFU70XFAN1 / KSRU70HFAN1/ KSFU120XFAN3 / KSRU120HFAN3

P4 - evaporator temperature protection

P5 - condenser temperature protection

P7 - discharge temperature is too high, compressor protection is on

P9 - the outside temperature is too low, when increased, the protection will turn off automatically

P10 - output pressure protection

P11 - suction pressure protection

P12 - overcurrent protection

E1 - internal temperature sensor T1 closed / torn off

E2 - evaporator temperature sensor T2 closed / disconnected

E3 - temperature sensor capacitor T3 closed / broken

E4 - outdoor temperature sensor closed T4 closed / torn

E5 - communication between indoor and outdoor units is broken

E6 - external unit protection

E10 - compressor suction pressure error

E13 - compressor phase error

E14 - incorrect phasing of the compressor

HS - start defrost